


D. Configuring IP Address Using the BIOS

1. Select the *IPMI* tab.
2. Select *BMC Network Configuration* and press <Enter>.
3. Highlight *Update IPMI LAN Configuration*, press <Enter> and select [Yes].



4. Highlight *Configuration Address Source* and select [Static].

